

How to install Touchwin USB driver in Win8

1. Change Win8 settings as the picture orders 1 to 8 (picture 12, 3, 45, 678).
2. Then try to install the USB driver.

If your system is win8 32bits, please install win7-32bits USB driver.

If your system is win8 64bits, please install win7-64bits USB driver.